

Mounting instructions Seat depth extension 508 and Abduction block 509

Note: If you want to install seat depth extension 508 and abduction block 509 then you must install abduction block first.

The abduction block 509 must be inserted into middle tube (red ellipse) and then fixed in position by tightening the allen screws (white arrow).

The seat depth extension 508 must be inserted as far as possible into both outer tubes (green rectangular) and then fixed in position by tightening the 2 allen screws (white arrows).

